

OxyGUARD™

**DISINFECTANT • FOOD CONTACT
SANITIZER • VIRUCIDE* CLEANER
DEODORIZER • FUNGICIDE**

DIRECTIONS

It is a violation of Federal law to use this product in a manner inconsistent with its labeling. Please read entire label and use strictly in accordance with precautionary statements and directions. Before using this product in in federally inspected meat and poultry food processing plants and dairies, food products and packaging materials must be removed from the room or carefully protected. This product is not for use on medical device surfaces.

FOR USE AS A SPORICIDE AGAINST Clostridium difficile SPORES:

1. Pre-clean surfaces. Fecal matter/waste must be thoroughly cleaned from surfaces/objects before disinfection by application with a clean cloth, mop, and/or sponge saturated with the disinfectant product. This cleaning may be accomplished with any cleaning solution, including this product. Cleaning is to include vigorous wiping and/or scrubbing, until all visible soil is removed. Special attention is needed for high-touch surfaces. Surfaces in patient rooms are to be cleaned in an appropriate manner, such as from right to left or left to right, on horizontal surfaces, and top to bottom, on vertical surfaces, to minimize spreading of the spores. Restrooms are to be cleaned last. Do not reuse soiled cloths.
2. Apply use solution of 4oz. of this product per gal. of water to disinfect hard, non-porous surfaces with a sponge, brush, cloth, mop, by immersion, mechanical spray device. For spray applications, spray 6-8 inches from surface. Do not breathe spray.
3. Treated surfaces must remain wet for 2 minutes.
4. Allow to air dry. Rinsing of floors is not necessary unless they are to be waxed or polished.
5. Prepare a fresh solution daily or when visibly dirty.

Note: Materials used in the cleaning process that may contain feces/wastes are to be disposed of immediately in accordance with local regulations for infectious materials disposal.

FOR USE AS A ONE-STEP, GENERAL, HOSPITAL DISINFECTANT, VIRUCIDE*, FUNGICIDE, DEODORIZER, CLEANER:

1. Pre-clean heavily soiled areas.
2. Apply use solution of 4oz. of this product per gal. of water to disinfect hard, non-porous surfaces with a sponge, brush, cloth, mop, by immersion, mechanical spray device. For spray applications, spray 6-8 inches from surface. Do not breathe spray.
3. Treated surfaces must remain wet for 2 minutes.
4. Allow to air dry. Rinsing of floors is not necessary unless they are to be waxed or polished.
5. Prepare a fresh solution daily or when visibly dirty.

FOR USE AS A ONE-STEP VIRUCIDE*:

1. Pre-clean heavily soiled areas.
2. Apply use solution of 2oz. of this product per 5gal. of water to disinfect hard, non-porous surfaces with a sponge, brush, cloth, mop, by immersion, mechanical spray device. For spray applications, spray 6-8 inches from surface. Do not breathe spray.
3. Treated surfaces must remain wet for 10 minutes.
4. Allow to air dry. Rinsing of floors is not necessary unless they are to be waxed or polished.
5. Prepare a fresh solution daily or when visibly dirty.

FOR USE AS A TUBERCULOCIDE:

1. Pre-clean heavily soiled areas.
2. Apply use solution of 4oz. of this product per gal. of water at 21°C to disinfect hard, non-porous surfaces with a sponge, brush, cloth, mop, by immersion, mechanical spray device. For spray applications, spray 6-8 inches from surface. Do not breathe spray.
3. Treated surfaces must remain wet for 10 minutes.
4. Allow to air dry. Rinsing of floors is not necessary unless they are to be waxed or polished.
5. Prepare a fresh solution daily or when visibly dirty.

***KILLS HIV-1, HBV AND HCV ON PRE-CLEANED HARD, NON-POROUS SURFACES/OBJECTS PREVIOUSLY SOILED WITH BLOOD/BODY FLUIDS** in health care settings or other settings in which there is an expected likelihood of soiling of hard, non-porous surfaces/objects with blood or body fluids and in which the surfaces/objects likely to be soiled with blood or body fluids can be associated with the potential for transmission of Human Immunodeficiency Virus Type 1 (HIV-1) (associated with AIDS), Hepatitis B Virus (HBV) and Hepatitis C Virus (HCV). **SPECIAL INSTRUCTIONS FOR CLEANING AND DECONTAMINATION AGAINST HIV-1, HBV AND HCV ON SURFACES/OBJECTS SOILED WITH BLOOD/BODY FLUIDS.**

Personal Protection: Wear protective latex gloves, gowns, masks and eye protection.

Cleaning Procedure: Blood and other body fluids must be thoroughly cleaned from hard, non-porous surfaces and objects before application of this product.

Disposal of Infectious Materials: Blood and other body fluids, cleaning materials and clothing must be autoclaved and disposed of according to federal, state and local regulations for infectious waste disposal.

Contact Time: Allow surface to remain wet for 2 minutes for HIV-1, 5 minutes for HBV and HCV at 4oz. of this product per gal. of water.

Application:

- Recirculating Spray - CIP and COP Washer
- Immersion and Flow Cleaning
- Manual Cleaning
- Fogging, Dry-Fog



PRODUCT PROPERTIES

Color: Clear

Odor: Mild Vinegar-Like

pH: <1.0

Recommended Dilution: 1:32

Foam: Moderate

Contact CANI, Inc. for technical services or product recommendations.

610.222.4500 • CANIUSA.COM

