

FOR CRITICAL PROCESS CLEANING

# CANI

COMMITMENT TO CONSTANT AND NEVER ENDING IMPROVEMENT

# CP-700

## ALKALINE DETERGENT

**For Use On:**

Processing Equipment  
Laboratory Glassware, Plastics and  
Equipment  
Medical Devices

**Facilities:**

Pharmaceutical & Life Sciences  
Cosmetics  
Medical Device  
Food & Beverage  
Flavors and Fragrances

**DESCRIPTION:**

CP-700 is a concentrated liquid alkaline detergent used to clean process and research equipment in pharmaceutical, biotechnology, cosmetic, medical device and food and beverage facilities. It will remove a wide range of process and product residues, including proteins, organics, many excipients, and fine chemicals. CP-700 is low foam, extremely free-rinsing and is phosphate-free.

**DIRECTIONS FOR USE:** Typical operating concentrations of CP-700 vary from 0.4 to 10% by volume depending on temperature, soil loads, and cleaning methods used. Use in ultrasonics, immersion, pressure spray, and is ideal for recirculating glassware and spray washers and recirculating clean-in-place (CIP) systems. When used as directed, the product is safe for use on stainless steel, glass, and a wide variety of plastics. The product is not recommended for aluminum, copper and other soft metals. Always rinse food contact surfaces thoroughly with potable water after use of this product. NOTE: Proper care and protective equipment are required for manual cleaning – see MSDS sheet

Contact CANI, Inc. for technical services or product recommendations.



### PRODUCT SPECIFICATIONS

Form: Liquid  
Odor: characteristic  
pH1% solution: 12.3-12.8  
Specific Gravity: 1.245-1.290  
Solubility: complete  
Foam: low

**CANI, INC.**

1758 Allentown Road, Lansdale, PA 19446

Phone: (610) 222-4500

Fax: (610) 222-4203

[www.caniusa.com](http://www.caniusa.com)

CRITICAL PROCESS CLEANING

